


83-140 Removal and installation of ornamental grille on air inlet


Note

The ornamental grille is attached at the front with only four expanding clamps (arrows). Remove windshield wiper arms from windshield wiper shaft at driver's side.




Removal


- 1 Push bolt on expanding clamps completely down.



- 2 Lift expanding clamps on one side and take out of ornamental grill.



- 3 Pull out ornamental grill in forward direction.



Installation

- 4 For installation proceed vice versa.